

Contents

- 1 Background
- 2 Site Selection
- 3 Field Data Collection and Analysis
- 4 Regional Curve Development
- 5 Summary



1 Background





What's the Problem?

- Natural Channel Design is challenging
- Bankfull is critical
- Channels that need restoration seldom have reliable bankfull indicators





What is a natural channel?

- Alluvial or semi-alluvial
- In grade
- Fluvial processes not excessive
- Some bank erosion or deposition is expected





How is channel size estimated?

- HEC-RAS Theoretical
- Reference Reach Empirical (one site)
- Regional Curve Empirical (many sites)






How is channel size estimated?

- HEC-RAS Theoretical
- Reference Reach Empirical (one site)
- Regional Curve Empirical (many sites)

What is a Regional Curve?

Plot of bankfull area versus drainage area

Stantec Scientific Research and Experimental Development Grant: SCL-2013A-1603-07






Why use Regional Curves?

- Aid to designers
- Aid to regulators
- Independent check of other methods
- Simple application





2 Site Selection





Three Regions Selected

- Close to urban areas
- Areas where channel restoration likely
- •WATERLOO REGION
- PEEL REGION
- YORK-DURHAM REGION



Desktop Assessment

- Drainage areas 1 km² to 200 km²
- Similar geology and precipitation
- Unregulated flows
- Slope 0.5% 1.0%
- Safe access





Field Verification

- Stable channel
 - > Fluvial processes not excessive
 - ➤ Good floodplain connection
 - No sediment wedges
- Confirm geology
- Reliable bankfull features



Field Verification



3 Data Collection & Analysis





Equipment

- Survey grade GPS
- Total station
- Engineering rod & level and tape







Data Collected

Identifying Bankfull

- •Walk channel
- Look for consistency
- Local disturbances
- •Inner berm







Data Collected

- Channel cross-sections (width, depth, area)
- At riffles (3-4 if possible)
- Inner berm
- Slope, grain size
- Photographs





Data Analysis

- RiverMorph software
- Cross-sections plotted
- Dimension based on site average
- Plot bankfull dimension against drainage area
- Regression analysis



Inner Berm


- Common in alluvial channels
- Lower than bankfull
- Depositional feature
- Low flow channel
- Enhances habitat
- Enhances sediment transport






Data Analysis


East 16 Mile Creek Trib XS-1






4 Regional Curve Development






Waterloo Region

n = 12




York Durham Region

n = 9




Regional Comparison



Composite Curve

n = 31




Composite Curve

- Estimates of bankfull area in glacial sediments
- Waterloo, Peel and York-Durham Regions
- Inner berm area more sensitive to region





5 Summary



Regional Curves

- High correlation
- Represent actual stream dimensions in a region
- Check of other estimates of bankfull dimension





Regional Curves

- Support to designers
- Support to regulators
- Curve is incomplete





Questions?

